

Geographic Response Strategy Lower Cole River MHB01						
Tactic #	Purpose	Response Equipment	<b>Deployment Resources</b>	Deployment Notes		
DV-01	Redirect spilled oil from one location or direction of travel to a specific site for recovery.	1000 ft protected water boom 5 marine anchor system 2 shoreline anchor system 10/16/2018 Testing Date	2 shore responders 2 response boats 6 boat responders Y Tested	Tend through tidal changes. Deploy boom as depicted to divert incoming oil to the collection site. Anchor every 200-300'. Adjust angle as necessary to reduce entrainment. Set up shoreside recovery and tend throughout tide. Deploy shoreside anchor first.		
EX-02a	Prohibit oil slicks from entering a sensitive area	200 ft protected water boom 1 marine anchor system 2 shoreline anchor system Testing Date	2 shore responders 1 response boats 3 boat responders N Tested	Tend through tidal changes. Deploy boom as depicted to exclude oil from sensitive areas. Anchor every 200-300'. Not tide dependent. Deploy shoreside anchor first.		
EX-02b	Prohibit oil slicks from entering a sensitive area	400 ft protected water boom 2 marine anchor system 2 shoreline anchor system Testing Date	2 shore responders 1 response boats 3 boat responders  N Tested	Tend through tidal changes. Deploy boom as depicted to exclude oil from sensitive areas. Anchor every 200-300'. Not tide dependent. Deploy shoreside anchor first.		
EX-02c	Prohibit oil slicks from entering a sensitive area	200 ft protected water boom 1 marine anchor system 2 shoreline anchor system Testing Date	2 shore responders 1 response boats 3 boat responders N Tested	Tend through tidal changes. Deploy boom as depicted to exclude oil from sensitive areas. Anchor every 200-300'. Not tide dependent. Deploy shoreside anchor first.		
EX-02d	Prohibit oil slicks from entering a sensitive area	100 ft protected water boom	2 shore responders 1 response boats 3 boat responders N Tested	Tend through tidal changes. Deploy boom as depicted to exclude oil from sensitive areas. Anchor every 200-300'. Not tide dependent. Deploy shoreside anchor first.		
FO-03	Contain and recover spilled oil on the water in the offshore & nearshore environment	1 or more onwater skimming system	S	Deploy on-water recovery task force(s) in configuration suitable for types of vessels used and sea conditions, with skimming system(s) and temporary storage for recovered oil and water. Location not exact, will move to chase oil.		
		N/A Testing Date	Tested			
SR-04	Remove spilled oil that has been diverted to a designated recovery site accessible from shore	<ul><li>1 skimming system</li><li>1 storage tank or bladder</li><li>1 hoses, pumps, fittings</li></ul>	2 shore responders	Set up shoreside recovery tactic at general location depicted on map. Some access points located at private residences. Access may be difficult.		
		N/A Testing Date	Tested			

Geographic Response Strategy Lower Cole River MHB01

ecoproprie response strategy				
Local contacts				
Swansea Fire Department	508-672-4305			
5	F00 C4C 2010			
Somerset Fire Department	<u>508-646-2810</u>			
Fall River Fire Department	508-675-7411			
Dominion Energy Terminal	508-646-5000			
Mass. Dept of Environmental Protection (24	888-304-1133			
Hours)	333 33			
U.S. Coast Guard (24 Hours)	508-457-3211			
Swansea Conservation Commission	E09 672 6467			
Swansea Conservation Commission	<u>508-673-6467</u>			
Swansea Harbormaster	508-799-8693			
Naragansett Baykeeper (Save The Bay)	401-272-3540			

Resources Protected				
Marine Mammals	None identified			
Fish	Anadromous, Catadromous, Finfish			
Invertebrates	Lobster, crab, shrimp, shellfish			
Birds	Shorebirds, Seabirds, Nesting Areas			
Threat/End. Species	Piping Plover			
Cultural	None identified			
Subsistence	None identified			
Human Use	Beach, Boat Ramp, Marina			
Commercial Fishing	None identified			
Land Management	None identified			
Coastal Habitiat	Beach, Marsh/Swamp, Rocky, Tidal Flats			



Cove at Gardners Neck (EX-02c)



Site of EX-02d at Cedar Cove

## **Special Considerations & Navigational Hazards**

Important Bird Area (IPA) as designated by MassAudobon. Go to the Mass Audobon website (Conservation) for more information. Western shore south of DV-01 and down to the Rhode Island border is a known Piping Plover nesting area. Responders should not disturb nesting areas if encountered. Vessel operators should have local knowledge.