

Geographic Response Strategy Mattapoisett Inner Harbor BB16						
Tactic #	Purpose	Response Equipment	Deployment Resources	Deployment Notes		
EX-01a	Prohibit oil slicks from entering a sensitive area	600 ft protected water boom 3 marine anchor system 2 shoreline anchor system 06/09/15 Testing Date	2 shore responders 1 response boats 3 boat responders Y Tested	Tend through tidal changes. Deploy boom as depicted to exclude oil from sensitive areas. Anchor every 200-300'. Not tide dependent. Deploy shoreside anchor first. Readjust boom angle as needed to reduce entrainment		
EX-01b	Prohibit oil slicks from entering a sensitive area	600 ft protected water boom 3 marine anchor system 2 shoreline anchor system Testing Date	2 shore responders 1 response boats 3 boat responders N Tested	Tend through tidal changes. Deploy boom as depicted to exclude oil from sensitive areas. Anchor every 200-300'. Not tide dependent. Deploy shoreside anchor first.		
BB-02	Exclude spilled oil from impacting sensitive areas by constructing a barrier from natural materials	Build a beach berm. Use local beach & inter-tidal bar sediments. Don't destroy any part of foredune. If berm is expected to remain in place for more than a few days, place one or more 20' x 12" pipe in the channel & build berm on top of pipe. Use culvert plugs to control water flow through the pipe. Permitting may be required. N/A Testing Date Tested		Construction of beach berms typically require the use of heavy equipment and should only be attempted by professional responders. Beach berms should not be constructed without explicit direction from the UC. Permits for earth-moving to construct beach berms are required from state and federal agencies (MADEP, Army Corp. of Eng) and concurrence from Natural Resource Trustee Agencies may also be required.		
PR-03	Remove spilled oil by collecting it in a sorbent material	1200 ft sorbent boom 1200 ft sorbent pom-poms 34 anchor stakes N/A Testing Date	2 shore responders Tested	Place and stake snare or sorbent boom in areas that are likely to pool and collect oil and across the mouths of the streams and intertidal areas. Use snare boom for persistent oils and sorbent boom for non-persistent oils. Approach the streams and intertidal areas on rising tide. Replace as necessary to maximize oil recovery.		
PR-03	Remove spilled oil by collecting it in a sorbent material	950 ft sorbent boom 950 ft sorbent pom-poms 27 anchor stakes N/A Testing Date	2 shore responders Tested	Place and stake snare or sorbent boom in areas that are likely to pool and collect oil and across the mouths of the streams and intertidal areas. Use snare boom for persistent oils and sorbent boom for non-persistent oils. Approach the streams and intertidal areas on rising tide. Replace as necessary to maximize oil recovery.		

Geographic Response Strategy Mattapoisett Inner Harbor BB16

Local contacts			
Mattapoisett Fire Dept.	(508) 758-4150		
Mattapoisett Harbor Master	(508) 758-4191		
Mattapoisett First Responder	(508) 758-9669		
Mass DEP (24 hours)	(888) 304-1133		
Massachusetts Dept. of Fish and Wildlife	(508) 792-7270		
The Coalition for Buzzards Bay	(508) 999-6363		
USCG Sector Southeastern New England	(501) 457-3211		

Resources Protected				
Marine Mammals	None identified			
Fish	Shellfish, finfish			
Invertebrates	None identified			
Birds	Waterfowl concentration			
Threat/End. Species	None identified			
Cultural	None identified			
Subsistence	None identified			
Human Use	Recreational beach, town owned boat ramp			
Commercial Fishing	None identified			
Land Management	None identified			
Coastal Habitiat	Tidal flat and marsh system a river entrance, eel grass beds, sand and cobble beaches			



View of Mattapoisett River Inlet. (RPI photo.)



Mattapoisett River looking north at low tide. (10 Jan 2008)

Special Considerations & Navigational Hazards

Maximum estimated current 1.5 kts. Submerged rocks in area.