

Geograp	hic Response Strategy			Buttermilk Bay System BB27
Tactic #	Purpose	Response Equipment	Deployment Resources	Deployment Notes
DV-01	Redirect spilled oil from one location or direction of travel to a specific site for recovery.	1200 ft protected water boom 6 marine anchor system 2 shoreline anchor system Testing Date	2 shore responders 2 response boats 6 boat responders N Tested	Tend through tidal changes. Deploy boom as depicted to divert incoming oil to the collection site. Anchor every 200-300'. Adjust angle as necessary to reduce entrainment. Set up shoreside recovery and tend throughout tide. Deploy shoreside anchor first.
EX-02a	Prohibit oil slicks from entering a sensitive area	700 ft protected water boom 4 marine anchor system 2 shoreline anchor system Testing Date	2 shore responders1 response boats3 boat respondersN Tested	Tend through tidal changes. Deploy boom as depicted to exclude oil from sensitive areas. Anchor every 200-300'. Not tide dependent. Deploy shoreside anchor first.
EX-02b	Prohibit oil slicks from entering a sensitive area	200 ft protected water boom 1 marine anchor system 2 shoreline anchor system 10/03/19 Testing Date	2 shore responders 1 response boats 3 boat responders Y Tested	Tend through tidal changes. Deploy boom as depicted to exclude oil from sensitive areas. Anchor every 200-300'. Not tide dependent. Deploy shoreside anchor first.
вв-03 ВВ		Build a beach berm. Use local beach & inter-tidal bar sec foredune. If berm is expected to remain in place for mor 20' x 12" pipe in the channel & build berm on top of pipe flow through the pipe. Permitting may be required.	e than a few days, place one or more	Construction of beach berms typically require the use of heavy equipment and should only be attempted by professional responders. Beach berms should not be constructed without explicit direction from the UC. Permits for earth-moving to construct beach berms are required from state and federal agencies (MADEP, Army Corp. of Eng) and
FO-04	Contain and recover spilled oil on the water in the offshore & nearshore environment	N/A Testing Date 1 or more onwater skimming systems N/A Testing Date		concurrence from Natural Resource Trustee Agencies may also be required. Deploy on-water recovery task force(s) in configuration suitable for types of vessels used and sea conditions, with skimming system(s) and temporary storage for recovered oil and water. Location not exact, will move to chase oil.
SR-05	Remove spilled oil that has been diverted to a designated recovery site accessible from	1 skimming system 1 storage tank or bladder 1 hoses, pumps, fittings N/A Testing Date	2 shore responders Tested	Set up shoreside recovery tactic at general location depicted on map. Some access points located at private residences. Access may be difficult.

Geographic Response Strategy

Local contacts	
Bourne Fire Department	<u>(508) 759-4412</u>
Bourne DNR	<u>(508) 759-0600</u>
Wareham Harbor Master	<u>(508) 291-3100 x 3186</u>
Massachusetts Dept. of Fish and Wildlife	<u>(508) 792-7270</u>
The Coalition for Buzzards Bay	<u>(508) 999-6363</u>



View of Buttermilk Bay entrance looking east at low tide on 29 May 2004. (RPI photo)



Cohasset Narrows at the entrance to Buttermilk Bay looking east on 29 May 2008. (RPI photo)

ecial Considerations & Navigational Hazards

kts in nearby Cape Cod Canal.

Resources Protected				
Marine Mammals	None identified			
Fish	Shellfish, finfish			
Invertebrates	None identified			
Birds	Waterfowl concentration, Roseate Tern (federal/state endangered)			
Threat/End. Species	None identified			
Cultural	None identified			
Subsistence	None identified			
Human Use	Private docks, marinas, state college, and private and public beaches			
Commercial Fishing	None identified			
Land Management	None identified			
Coastal Habitiat	Marsh sheltered tidal-flats, barrier beach, eel grass beds, sand and cobble beaches, shoreline armament			