

Geographic Response Strategy Weweantic River System BB22							
Tactic #	Purpose	Response Eq	uipment	Deployment Resources	Deployment Notes		
DV-01	Redirect spilled oil from one location or direction of travel to a specific site for recovery.	2000 ft protected water boom 10 marine anchor system 2 shoreline anchor system Testing Date		2 shore responders 2 response boats 6 boat responders N Tested	Tend through tidal changes. Deploy boom as depicted to divert incoming oil to the collection site. Anchor every 200-300'. Adjust angle as necessary to reduce entrainment. Set up shoreside recovery and tend throughout tide. Deploy shoreside anchor first.		
PR-02	Remove spilled oil by collecting it in a sorbent material	2750	ft sorbent boom ft sorbent pom-poms anchor stakes Testing Date	2 shore responders Tested	Place and stake snare or sorbent boom in areas that are likely to pool and collect oil and across the mouths of the streams and intertidal areas. Use snare boom for persistent oils and sorbent boom for non-persistent oils. Approach the streams and intertidal areas on rising tide. Replace as necessary to maximize oil recovery.		
BB-03	Exclude spilled oil from impacting sensitive areas by constructing a barrier from natural materials	Build a beach berm foredune. If berm i 20' x 12" pipe in th	n. Use local beach & inter-tidal bar sedim s expected to remain in place for more t e channel & build berm on top of pipe. U ipe. Permitting may be required. Testing Date	nents. Don't destroy any part of han a few days, place one or more	Construction of beach berms typically require the use of heavy equipment and should only be attempted by professional responders. Beach berms should not be constructed without explicit direction from the UC. Permits for earth-moving to construct beach berms are required from state and federal agencies (MADEP, Army Corp. of Eng) and concurrence from Natural Resource Trustee Agencies may also be required.		
FO-04	Contain and recover spilled oil on the water in the offshore & nearshore environment	1 or more onwater skimming systems		Tested	Deploy on-water recovery task force(s) in configuration suitable for types of vessels used and sea conditions, with skimming system(s) and temporary storage for recovered oil and water. Location not exact, will move to chase oil.		
SR-05	Remove spilled oil that has been diverted to a designated recovery site accessible from shore	1	skimming system storage tank or bladder hoses, pumps, fittings Testing Date	2 shore responders Tested	Set up shoreside recovery tactic at general location depicted on map. Some access points located at private residences. Access may be difficult.		

Geographic Response Strategy Weweantic River System BB22

Local contacts	
Marion Harbor Master	<u>(508) 748-3535</u>
Marion Fire Department	<u>(508) 748-1177</u>
Wareham Fire Department	(508) 295-2973
Wareham Harbor Master	(508) 291-3100 x 3186
Massachusetts Dept. of Fish and Wildlife	<u>(508) 792-7270</u>
The Coalition for Buzzards Bay	(508) 999-6363

Resources Protected					
Marine Mammals	None identified				
Fish	Shellfish, finfish				
Invertebrates	None identified				
Birds	Waterfowl concentration				
Threat/End. Species	None identified				
Cultural	None identified				
Subsistence	None identified				
Human Use	Small mooring field (app. 100 boats), several private docks				
Commercial Fishing	None identified				
Land Management	None identified				
Coastal Habitiat	Extensive coastal river system with tidal flats and marsh grasses along river banks, eel grass beds, sand and cobble beaches				



Entrance to Weweantic River (DV-01 center left) at low tide on 29 May 2004. (RPI Photo)

Site photo provided for reference

Special Considerations & Navigational Hazards

Large waves can form if wind is from SE.